



PYROMASTER LLC
TAMING THE SKIES

Instructions for **SS Slim Line Manual** Battery 24 V NIMH Charger

1. Plug Charger connector to the SS-128 Slim Line Controller
2. Plug Charger into 110/AC
3. Slim Line Power Light:
 - Red = Charging with Controller power switch in the Ext position
 - Orange = Charging with Controller power switch in the INT position.Note System is charging and operational at the same time

Note: Manual charging should not exceed 12 hours. Over charging can effect battery life and create battery damage.

IMPORTANT SAFETY INSTRUCTIONS AND WARNINGS For NIMH **BATTERIES**

- Never make wrong polarity connection when charging and discharging battery packs. Always double check polarity of battery's connector to make sure red wire to red wire and black wire to black wire.
- NiMH battery without an attention may cause battery to explode. Note the Charge amperage is under 500 ma
- When charging NiMH battery, please always put the battery in a water-proof place to avoid any accidents.
- Suggest you charging NiMH batteries and packs at least every six months, otherwise NiMH battery will reduce capacity or dead. For safety reason, we usually ship NiMH battery without fully charged. You must charging NiMH battery before use, and allow 3-5 cycles of charging and discharging for battery capacity to recovered.